



W
Z
E
Y
S

Instructions for Unpacking a Door Crate

Important!!! Every Step Must Be Followed Precisely & In The Exact Order Outlined Below:

Step 1: Remove the plastic wrap (*Diagram 1*).

Step 2: Remove the 1X4 boards along the top of door pack. (Parts A & B, *Diagram 2*).

Step 3: Cut Wire Straps (Part G & H, *Diagram 2*).

Step 4: Remove the lumber that was used to position the wire straps. (Part C & D, *Diagram 2*).

Step 5: Remove the particle board end cap (Part E, *Diagram 2*).

Step 6: Remove the top cardboard (Part F, *Diagram 2*).

Step 7: Remove the individual doors (*Diagram 3*).

