# Remove Hinge KIT

Locate the Screw:

Identify the screw that secures the Hinge Kit in place. (Figure 1)

Unscrew:

Using a Hex L-Key 5/32 unscrew the screw.

Remove the Hinge Kit:

Once the screw is removed, you can proceed to detach the Hinge Kit from its position. (Figure 2)



Carefully detach the retainer ring from its position. Make sure to handle it gently to avoid any damage. (Figure 2)

• Flip the Cam:

Once the retainer ring is removed, rotate the cam to the opposite position. Ensure that it is securely in place after flipping. (Figure 3)

Reattach the Retainer Ring:

After successfully flipping the cam, reattach the retainer ring to secure everything in its new configuration. (Figure 3)



Figure 1





Figure 2








Figure 3





We have 3 rivets for each bracket, remove the rivets using the drill. Please follow the instructions below to complete this task.



Figure 1



Figure 1

#### Preparation:

- Ensure you have the appropriate drill and drill bits for rivet removal.
- Wear safety goggles and protective gear to ensure your safety.

#### **Removal Process:**

- Locate the three rivets for each bracket. (Figure 1)
- Use the drill to carefully remove each rivet.
- Make sure to maintain control of the drill to avoid damaging the bracket or surrounding areas.



# **Hinge Kit Assembly**

#### Positioning:

• Place the hinge kit on the opposite side. (Figure 1)

#### Securing:

• Use the same screws that were removed to secure the hinge kit in its new position. (Figure 2)







Figure 1 Figure 2

## **Reversible KIT Parts**

KIT will have 2-brackets(Top & Bottom), 6 rivets & retainer ring in the package





## **Bracket Installation**

#### Alignment:


 Begin by aligning the brackets with the handle side for proper positioning. (Figure 1)

#### Riveting:

 Proceed to rivet the bracket to the aluminum extrusion securely. (Figure 1)

#### Final Check:

 After installation, double-check that everything is aligned and secured properly.



**Rivet Position** 



Figure 1

# **Replacement Parts KIT:**

Hinge	Part No	Description
Right	1000004500	RH REVERSIBLE KIT - CONVERTING LH DOOR TO RH SWING
Left	1000004501	LH REVERSIBLE KIT - CONVERTING RH DOOR TO LH SWING

